




ANGLE STOP MOUNT



	
CONNECTICUT SCREEN WORKS, INC Wallingford, CT 06492 (203) 741-0859	
Title: Angle Stop Mount	
Date: 08/01/06	By: MC
Scale: N/A	Rev:08/01/06 by MC
Page: 1 of 6	Rev:02/02/2012 by MC
Alloy:	Rev:
Temper:	Patent: 7,938,163
Length:	Others Pending
Die:	
all contents copyright 2006, 2012 by CSW, Inc.	

ANGLE STOP MOUNT

MEASURING:


- 1) Measure each opening height and width. Measure in several locations (top, middle, bottom, left side, center, right side, etc.) and record all measurements taken.
 - 2) The maximum difference between the widest and smallest width obtained in your opening cannot be more than 1/4". This is true for the height measurements also. If you are out by over 1/4" you will need to modify your openings to correct this prior to measuring any further.
 - 3) Provided your openings are within the maximum standard noted in #2 above, subtract 1/2" from the smallest width and smallest height obtained in each opening.
 - 4) The resulting sizes would be your true manufacture size for each panel or wall being ordered.
- Plan carefully if you modify this installation since very little room for error exists.

NOTICE:

Review all information provided. There may be important information, restrictions, limitations, and recommendations concerning this mounting suggestion that can effect measurements taken and your final manufacture sizes submitted for order.



All information and directions provided herein should be treated as a generic guide which is intended to help you plan, measure and order screens. The directions herein are applicable and correct for a great majority of situations - but not all. In some situations these directions and/or your structure may need to be modified and in some, these directions should not be used. The responsibility to determine this and the responsibility to order items correctly rests solely on the customer. We make no guarantee, warrantee or promise of any kind that these directions will work in every application. Please read and understand all information provided herein and on our web sites. Web site data always supercedes printed matter


In all cases, be sure to consult and follow all local building codes.

	
CONNECTICUT SCREEN WORKS, INC Wallingford, CT 06492 (203) 741-0859	
Title: Angle Stop Mount	
Date: 08/01/06	By: MC
Scale: N/A	Rev: 08/01/06 by MC
Page: 2 of 6	Rev: 02/02/2012 by MC
Alloy:	Rev:
Temper:	Patent: 7,938,163
Length:	Others Pending
Die:	
<small>all contents copyright 2006, 2012 by CSW, Inc.</small>	

ANGLE STOP MOUNT

TOP DOWN VIEW OF TWO ADJOINING MASTER FRAME PANELS





 CONNECTICUT SCREEN WORKS, INC Wallingford, CT 06492 (203) 741-0859	
Title: Angle Stop Mount	
Date: 08/01/06	By: MC
Scale: N/A	Rev: 08/01/06 by MC
Page: 3 OF 6	Rev: 02/02/2012 by MC
Alloy:	Rev:
Temper:	Patent: 7,938,163
Length:	Others Pending
Die:	
all contents copyright 2006, 2012 by CSW, Inc.	

ANGLE STOP MOUNT



SIDE VIEW OF TOP MASTER FRAME





 CONNECTICUT SCREEN WORKS, INC Wallingford, CT 06492 (203) 741-0859	
Title: Angle Stop Mount	
Date: 08/01/06	By: MC
Scale: N/A	Rev: 08/01/06 by MC
Page: 4 OF 6	Rev: 02/02/2012 by MC
Alloy:	Rev:
Temper:	Patent: 7,938,163
Length:	Others Pending
Die:	
all contents copyright 2006, 2012 by CSW, Inc.	

ANGLE STOP MOUNT



SIDE VIEW OF LOWER MASTER FRAME




 CONNECTICUT SCREEN WORKS, INC Wallingford, CT 06492 (203) 741-0859	
Title: Angle Stop Mount	
Date: 08/01/06	By: MC
Scale: N/A	Rev: 08/01/06 by MC
Page: 5 OF 6	Rev: 02/02/2012 by MC
Alloy:	Rev:
Temper:	Patent: 7,938,163
Length:	Others Pending
Die:	
all contents copyright 2006, 2012 by CSW, Inc.	

ANGLE STOP MOUNT

OPTIONAL


Although not required with stock finishes, a bond breaker is recommended for added protection when products are installed on metal or new pressure treated materials.




If installed on newer pressure treated lumber use stainless steel installation screws.

Hard plastic spacers may be used to help align panel in opening.

Along base, 3/16" plastic washers may be installed under angle and stop to provide weep opening.


	
CONNECTICUT SCREEN WORKS, INC Wallingford, CT 06492 (203) 741-0859	
Title: Angle Stop Mount	
Date: 08/01/06	By: MC
Scale: N/A	Rev: 08/01/06 by MC
Page: 6 of 6	Rev: 02/02/2012 by MC
Alloy:	Rev:
Temper:	Patent: 7,938,163
Length:	Others Pending
Die:	
all contents copyright 2006, 2012 by CSW, Inc.	



Screw pattern is the same for all mounts and installations. Stainless steel color matching trim head deck screws preferred but hardware should be adjusted as needed based upon substrate material.

- Panels and walls utilizing inserts:
6" from outside edge then no more than 24" apart.

- Panels and walls NOT utilizing inserts:
6" from outside edge then no more than 36" apart.

	
CONNECTICUT SCREEN WORKS, INC Wallingford, CT 06492 (203) 741-0895	
Title: Screw Patterns	
Date: 12/01/2011	By: MC
Scale: N/A	Rev:
Page: 1 OF 1	Rev:
Alloy: N/A	Rev:
Temper: N/A	Patent: 7,938,163
Length: N/A	<i>Others Pending</i>
Die:	
<small>all contents copyright 2006 by CSW, Inc.</small>	